
Working Process:**Blending-in with Basecoat into adjacent panels**

Substrate:

- Prepare new panels as usual, see Standox Painting System S3

**Pretreatment /
Cleaning:**

- Sand adjacent areas with P800 and an ultra fine pad



For substrate preparation information see Standox Painting System S1.

Painting:

- Apply Standox Basecoat Colourless
- Apply Standox Basecoat to new panel until complete opacity has been reached
- Fade out the surrounding area with reduced air pressure (by 0.5 - 1.0 bar).
- Apply Standocryl 2K Clear to entire repair panel